

OBSOLETE Pulsox-300i Component Card V1.6

Pulsox-300i 1732-311 (no longer available)



****Wrist band
Standard WB-300 5pk 1732-605**



AAA battery



****Reusable Wrist band
Long 5pk 1731-605LONG**



***Single-use elastic velcro
strap, 1 pk
VCKM**



***Extension Cable EC-300 for
Pulsox 300 series, 1m 1732-760
(no longer available)**



***USB Adaptor UA-300 1732-755**



***Visi-Download for Konica-Minolta**



****Finger Mesh Cover, 10pk
CH8250**



****Finger Mesh Cover, black, 3pk
1728-613**



****Soft tip sensor
Large ENV-L-KM
Adult ENV-M-KM
Small ENV-S-KM**



****Standard sensor CH8196**



****Spot check probe SP-5C
(no longer available)**



****Semi-disposable probe
Standard SD-5C
(no longer available)
Small SD-5C (20)
(no longer available)**



****Ear sensor ES-2182-3**



****Universal sensor CH8017
(no longer available)**